

Product Information

Applicable product:	
Top-mount kitchen sink - with one hole	K-5872-1A1
Top-mount kitchen sink - with three holes	K-5872-3A1
Top-mount kitchen sink - with four holes	K-5872-4A1
Under-mount kitchen sink - with five holes	K-5872-5UA1

Fixture*:	
Bowl area	22-1/4" (565 mm) x 15-13/16" (402 mm)
Water depth	9" (229 mm)
Drain hole	Ø 3-7/8" (98 mm)
Faucet holes:	
Top-mount models	Ø 1-3/8" (35 mm)
Under-mount model	Ø 2-3/8" (60 mm)
* Approximate measurements for comparison only.	

Included components:	
Under-mount sink kit 23" (584 mm)	1054375
Bottom bowl rack	K-6238
Cutout template	1172565-7

Recommended accessories:	
P-Trap	K-9000

Optional accessories:	
Utility rack with soaking cup	K-6194
Colander with integral cutting board	K-6239
Wood cutting board	K-6246
Duostrainer® sink strainer	K-8801

Installation Notes

Install this product according to the installation guide.

NOTICE: Countertop manufacturer or cutter **must** use the cutout template provided with the product, or a current one provided by Kohler Co. (call 1-800-4-KOHLER). Kohler Co. is not responsible for cutout errors when the incorrect cutout template is used.

IMPORTANT! Use of the colander, wood cutting board, and utility rack requires the "reveal" cutout option on the cutout template.

Fixture conforms to ASME Standard A112.19.1/CSA B45.2. All dimensions are nominal.

